



TIFOO

SILVER PATINATION

MANUAL

SILVER PATINATION



Security

The patination contains concentrated acid (hydrochloric acid).

Wear protective gloves and protective glasses.

Use only in well ventilated places - risk of piercing vapours (hydrochloric acid).

Avoid contact with food.

Possible to reduce the formation of vapours by light dilution.

IF ON SKIN: Wash with plenty of water.

Please read our safety data sheet for this product and the respective instructions on the label before first use.

Application fields

Blackening of silver and silver alloys (sterling silver 800, 830 and 925). For copper and its alloys, please use our copper and brass patination.

Using the silver patination

Take the patination with a (synthetic) brush or a plastic stick (both acid-resistant) and apply the patination on the silver. The silver will get darker or even black when in contact with the patination. Please use only acid-resistant materials like plastic or glass for the application and do not use any metal points or similar things. The patination is very persistent and as a consequence, you can polish the object with a cloth without wiping it off. You can take away excess patination with a paper towel. If necessary, it's possible to dilute the patination with the same amount of water. Further diluting will make the patination useless.

Promotion

Our company is officially sponsored by the European Union.



European Union

European Regional
Development Fund

TIFOO - a brand of

MARAWE GmbH & Co KG

Donaustauer - Str. 378
Gebäude 64
93055 Regensburg

Tel.: +49 941 29020439
Fax: +49 941 29020593
e-mail: info@tifoo.de
Web: www.tifoo.de